PIEDMONT PLUG™

SEAL THE MULLION. STOP THE SOUND.



*Visit **PiedmontPlug.com** for more information!*

Installation Instructions:

1. Locate and clean the face of window mullion. Remove all dust and debris from the mullion prior to installation.



Ritz Acoustics | info@piedmontplug.com

PIEDMONT PLUG™

SEAL THE MULLION. STOP THE SOUND.



*Visit **PiedmontPlug.com** for more information!*

Installation Instructions:

2. Use a caulk gun to seal all gaps between end of drywall partition and window mullion with acoustical sealant.



Ritz Acoustics | info@piedmontplug.com

PIEDMONT PLUG™

SEAL THE MULLION. STOP THE SOUND.



*Visit **PiedmontPlug.com** for more information!*

Installation Instructions:

3. Apply spots of silicon adhesive every 12 inches to help bond the Piedmont Plug.



Ritz Acoustics | info@piedmontplug.com

PIEDMONT PLUG™

SEAL THE MULLION. STOP THE SOUND.



*Visit **PiedmontPlug.com** for more information!*

Installation Instructions:

4. Align and insert the Piedmont Plug.



Ritz Acoustics | info@piedmontplug.com

PIEDMONT PLUG™

SEAL THE MULLION. STOP THE SOUND.



*Visit **PiedmontPlug.com** for more information!*

Installation Instructions:

5. Press the entire plug firmly in place to allow a proper bond with the adhesive.



Ritz Acoustics | info@piedmontplug.com